

# Printing- Calibrating Specimen Label printers



**Digital Health**  
CONNECTING BEST CARE

Digital Health  
Quick Reference Guide

**This Quick Reference Guide will explain how to:**

Calibrate Specimen Label Printers

## Mobile Devices

The alignment of these wireless printers is sensitive to rough handling and misalignment on these devices is often caused by 'tugging' a label sideways to tear it off, causing the next label to shift alignment.

1. Press the blue feed button on the front of the printer (not pictured)
2. The printer will produce a blank label.
3. In more extreme cases: open the door of the label compartment and manually re-seat the label roll in the feed guides.
4. Print the specimen labels you require and tear off against the serrated edge, carefully.



## Hard Wired (Desktop) Devices

Hardwired label printers exist, but none of them are used for EMR Accession label printing, at this time.

1. Ensure the top cover is closed as shown on the photo
2. Turn the printer on
3. Press and hold the green feed button for several seconds
4. The green LED will flash a number of times in sequence
5. When it flashes TWICE, release the button
6. The printer will the calibrate and produce a number of labels



### Important

- If you are still unable to print satisfactory specimen labels despite following the above instructions, please contact ICT so they can investigate and further assists.